

LVR2 Parts Placement

Rev A 12/97

Q1 notes:

Installation is with leads bent down, label up, and body hanging over top
 The TAB is the same as Bulb -, so be careful not to short
 A heatsink is recommended above 7 Amps and needed above 10 Amps

